

CHEMICLEAN PRODUCTS

TECHNICAL INFORMATION SHEET

OC14 - OVEN CLEANER GEL

Also, available as a Liquid in 750ml Trigger Spray Bottles

OC14 is a blend of caustic alkalis and special surface-active agents, which combine to provide a powerful degreaser for removing baked-on deposits of fats, grease and oil from ovens, cooking utensils, deep fat fryers and other kitchen equipment.

OC14 OVEN CLEANER GEL is packed in 5 litre containers.

Features

Versatile

Benefits

OC14 is ideal for the cleaning of all hot ovens, grills and hot plates. **OC14** is effective on vitreous enamel, cast iron, copper, brass and glass and most similar materials used for cooking purposes

Easy to Use

Simply spray **OC14** onto a warm or hot surface and wipe with a soft, damp cloth to leave surface sparkling clean

Fast Acting

OC14 is supplied as a cling-thick liquid which immediately activates on contact with the surface to be cleaned

Effective


OC14 quickly penetrates and removes fats, grease and oil from dirty surfaces

Directions for use

OC14 should be used as supplied, simply spray or sponge onto the surface. For best results, the surface should be preheated to approximately 60 degree C (140 degree F) Leave the **OC14** for up to 10 minutes before rinsing using clean water. For stubborn deposits, repeat the application

N.B. ALWAYS use rubber gloves when handling **OC14**. **DO NOT** use **OC14** on aluminium surfaces.

PO BOX 2487
HOCKLEY
BIRMINGHAM, B18 5JN
Telephone: 0121-523 8833
Fax: 0121-554 1137
Email: sales@chemiclean.co.uk
Website: www.chemiclean.co.uk



British Institute of
Cleaning Science

Quality and Service with a Smile!!!